

USE THE REFERANCE DIMENSIONS SHOWN
TO CHECK THAT YOUR ARTWORK IS SCALED
PROPERLY WHEN PRINTING. GET THE
SCALING AS CLOSE AS POSSIBLE BEFORE
YOU ATTACH YOUR PATTERNS TO THE
METAL.